




WB 17X210
G.E. Receptacle Assembly
and Terminal Block - Plastic.



WB 17X5095
G.E. Receptacle Assembly
and Terminal Block.



WB 17X5051
G.E./Hotpoint Ceramic
Receptacle. For Original G.E.
Style Plug-in Burners.




WB 17X5113
G.E./Hotpoint Plastic
Receptacle. Fits Regular Style
Burners.



WB 5X5002
G.E./Hotpoint Terminal.



WB 17X105
G.E./Hotpoint Contact Block.
WB 2X574 EA
G.E./Hotpoint Clips for Blocks.



WB 23X33
G.E./Hotpoint Push Button
Switch.



WB 23X5102 (WB 23X40)
G.E./Hotpoint Push Button
Switch 1" Stems.



WB 21X5243
G.E./Hotpoint Push to Turn
Switch Kit. 1 5/8" Break Off
Shaft. (5500-212).



WB 23X5070
G.E./Hotpoint
Switch for 3 Wire Burner
CW, 1/2" D-Stem Shaft.



WB 21X5237
G.E. Infinite Heat Switch,
Push to turn, 3/4" Shaft.



WB 21X5246
G.E. Infinite Heat Switch,
Push to turn, 1" Break off
Shaft.



WB 23K5027
G.E. Element Control,
Push to turn, 3/4" Shaft.



WB 23M24
G.E. Element Control, 1500W,
Push to turn, 3/4" Shaft.



WB 21X184
G.E./Hotpoint Responder
Switch Use with sensor
WB 21X5207.



WB 21X5207
G.E./Hotpoint
Surface Unit Sensor Yellow.
WB 21X5054
G.E./Hotpoint Surface Unit Sensor White.



WB 21X162
G.E. Responder.



WB 2X7909
G.E. Anti-Tip Kit.